

Installation Instructions

Part: Front Tow Hook

Front tow hook installs with existing hardware and holes

Part: Rear Tow Hook

Tools needed: Impact gun, 9/16" socket, 3/8 drill bit and electric drill.

Please follow the easy but important steps listed below

1. Feed the nut up through the bottom beside the stock tow hook with your left hand and place it over the existing round hole. (located below the oval hole)
2. Hold the nut in place with your right index finger inserted through the oval hole.
3. Align the Rear Tow Hook over the existing round hole and tighten the bolt into the nut by hand as much as possible.
4. Tighten the bolt with 9/16" socket using impact gun.
5. Drill a 3/8" hole into the car thru the side of the Rear Tow Hook. (Tip: It might be easier to make a pilot hole first)
6. After the hole is drilled, Loosen the first bolt just enough to drop the Rear Tow Hook down.
7. Insert the second nut with left hand through the bottom; assume the control of the nut with right finger after it is positioned over the new hole.
8. Realign the Rear Tow Hook hole with the newly drilled hole and tighten the second bolt into the second nut by hand.
9. Tighten the first hole by hand again and then tighten both bolts with impact gun. You are now ready to go.

